

ALL AROUND-SOLUTION FOR EACH APPLICATION



HiFIT

High Frequency Impact Treatment

THE HiFIT ANGLE ATTACHMENT

WWW.HIFITUSA.COM

WWW.HIFIT.DE

HiFIT ANGLE ATTACHMENT HF08-30 ARTICLE NO.: 3100



A COMPLEMENT THAT MAKES SENSE

The HF08-30 angle attachment is used in conjunction with a HiFIT device for post weld treatment of weld seams in areas that are difficult to access.

For the correct application of the HiFIT process, it is essential that an angle of 70 – 90 ° to the base material is maintained. However, this can be difficult for design reasons. The HF08-30 angle attachment is an effective solution here.

The angle attachment is cranked by 30 ° and can easily be mounted in eight different positions on the HiFIT device.

The scope of delivery includes a tool case with replacement pins and some useful tools for assembling and maintaining the angle attachment.

